



Installation Instructions: MS-900 Self Adhesive Pipe Marker

Pipe surface or insulation must be clean and dry. (If dirt, dust, oil or other contaminants are present, use a degreasing cleaner to remove any surface contamination) Using a damp paper towel add a small amount of liquid dish soap. Wipe the decal surface thoroughly using light pressure to remove any dust or grease. Wipe with a clean wet paper towel and again with a clean dry paper towel to remove any leftover soap or residue.

1 Remove the paper liner from the backside of the marker to expose the adhesive



2 Align and lightly adhere one end of the marker to the pipe or insulation



3 Smooth the marker from one side to the other using pressure to fully apply



4 Apply arrow tape 360 around pipe, to include end of pipe marker





Installation Instructions: MS-900 Self Adhesive Pipe Marker

5

Ensure arrows are in the correct
direction



6

Wrap both ends of label with arrow
tape

